



PART NUMBER : AMT12-2

DESCRIPTION : TRICKLE CHARGER

The **AMT12-2** has many names Trickle Charger, Battery Maintainer, Battery Saver, Reverse Charger, Top Up Charger, Battery Equaliser and its purpose is to keep a Source / Vehicle Battery charged and protected from damage during both short and prolonged periods of Vehicle, Boat and Motorhome inactivity or storage. The charger feeds a low current into the Source Battery to compensate for self discharge, alarm and tracker loads while ensuring the charge of the Auxiliary / Leisure Battery is maintained. In the ideal scenario a Solar Charger or Mains Charger is attached to an Auxiliary / Leisure Battery to protect it from damage during the period of inactivity and the Trickle Charger draws a small current off to maintain the Vehicle / Source Battery.

The Trickle Charger also feeds charge from the Auxiliary Battery to the Vehicle Battery until they reach 11.5V and 11.7V respectively ensuring that both Batteries are kept as healthy as possible even if no Solar Charger or Main Charger is present.

The unit has 8 User selected programmes and so is suitable for use with any Auxiliary Battery Charging System including a simple Voltage Sensing Relay and a Battery to Battery Charger.

It does not matter the Make or Type of B2B Charger the **AMT12-2** will Charge the Vehicle Battery from the Leisure Battery and the clever software means it is compatible with conventional Alternator Vehicles, the latest Stop / Start & Euro 5/6 and Regenerative Braking Technologies.

The unit has a low current draw of less than 2mA on a 12V system and so presents a very small discharge load to the Vehicle and Leisure Battery. At 1Ahr drain every 20 days the unit has negligible effect on the Battery Capacity and should have negligible effect on battery states of charge during a winter storage period.

When a charging source either a Mains Charger or a Solar Charger is connected to the Auxiliary / Leisure Battery the **AMT12-2** Trickle Charger allows a maximum of 4A (Usually considerably less) to flow from the Leisure Battery to the Vehicle Battery thus ensuring the Leisure Battery is Charged first and the Vehicle Battery second.

The **AMT12-2** works with all types of Lead Acid Batteries and Lithium Batteries, The Status Led gives feedback on the Trickle Charger Operation and State of Charge of the Vehicle Battery and Auxiliary Battery Conditions. There is Ignition Override and Switch Enable to allow the user to externally control the charging if for some reason they wish to override the automatic settings. The **AMT12-2** Trickle Charger works on 12V to 12V systems and 24V to 24V Battery Systems, Automatically detecting whether it is connected to a 24V or 12V system.

The **AMT12-2B** Trickle Charger contains an in built bluetooth dongle allowing the user to easily set the charging thresholds of the AMT to suit their specific application with a app on their android or apple phone. The app also allows the user to monitor the states of the vehicle and the auxiliary battery in real time. The compact potted plastic enclosure means the AMT12-2 is easily fitted next to the Auxiliary Battery Charger and connected by 3 Faston connections, (Leisure +ve , 0V and Vehicle +ve) The Inbuilt Fuse helps make te Installation extremely quick and easy.

There is a full range of AMT trickle chargers for 12V to 12V; 12V to 24V; 24V to 24V and 24V to 12V systems so if this unit does not fit your requirements lease look at the other products in the range or ring our office.

This product has been Developed by Ablemail as part of a Range & if this product does not meet your requirement, Please contact our Technical Department to see if we can meet your exact needs.

The Trickle Charger / Battery Maintainer programmed modes are : (Settings 1-4 are for low parasitic loads / Settings 5-8 are for higher parasitic loads and the AMT12-12-5 or AMT24-24 should be used if the AMT12-2 cannot deliver enough current to support the parasitic loads.)

	Charger Type	Leisure Battery Threshold	Vehicle Battery Threshold	Battery Type
Setting 1 / 5	Standard Alternator / Ignition	Leisure Battery >13.0V	Vehicle Battery >12.8V	All types of Lead Battery
Setting 2 / 6	Standard Alternator / Ignition	Leisure Battery >13.5V	Vehicle Battery >12.8V	Lithium Battery
Setting 3 / 7	Smart Alternator	Leisure Battery >13.5V	Vehicle Battery >12.4V	Lithium Battery
Setting 4 / 8	Smart Alternator	Leisure Battery >13.0V	Vehicle Battery >12.4V	All types of Lead Battery

